



# WHATSMINER

## Product Manual





# CATALOG

## M30 SERIES

01	M30S++	01
02	M30S+	03
03	M30S	05
04	M31S+	07
05	M31S	09
06	M33S++	11
07	M33S+	15

## M50 SERIES

08	M53	19
09	M50S	23
10	M50	25

# WHATSMINER M30S++

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatminer.com](mailto:Support@microbt-whatminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	112T ± 5%	Size	430mm*155mm*226mm
Power Ratio	31J/T ± 5% @25° C	Weight	11.7KG
Power On Wall	3472W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

# WHATSMINER M30S+

## Air Cooling



Components

Power Supply, Fan, Control Board, Hash Board, Case

Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

Warranty Period

One year after leaving the factory

After-sales Contact Information

1. Email: [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)
2. Telegram Group: @WhatsMiner Community

### SPECIFICATION

Hashrate	100T ± 5%	Size	430mm*155mm*226mm
Power Ratio	34J/T ± 5% @25° C	Weight	11.7KG
Power On Wall	3400W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

# WHATSMINER M30S

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	88T ± 5%	Size	430mm*155mm*226mm
Power Ratio	38J/T ± 5% @25° C	Weight	11.7KG
Power On Wall	3344W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		



# WHATSMINER M31S+

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	80T ± 5%	Size	430mm*155mm*226mm
Power Ratio	42J/T ± 5% @25° C	Weight	11.7KG
Power On Wall	3360W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

# WHATSMINER M31S

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	72T ± 5%	Size	430mm*155mm*226mm
Power Ratio	46J/T ± 5% @25° C	Weight	11.7KG
Power On Wall	3312W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

# WHATSMINER M33S++

## Hydro Cooling



### SPECIFICATION

Hashrate	220T ±10%
Power Ratio	31J/T ± 5%
PSU	AC380V, 3W+ ground, input 10kw
Size	86mm*482.6mm*650mm
Weight	Net weight: 27.5kg    Weight with packaging materials: 30kg
Coolant demand per machine	About 1L
Power Cable Model	Custom made
Internet Connections	Ethernet

### ENVIRONMENTAL PARAMETERS

- Liquid temperature
- Working temperature (inlet): 20°C~50°C@normal mode  
20°C~40°C@high performance mode;
  - Inlet temperature control accuracy ± 2°C
  - Storage and transportation temperature: -40~70°C

Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.

- Liquid flow
- Limited Data: ≥10L/min
  - Flow control accuracy ± 10%

Remarks: 10L/min corresponds to the temperature difference between inlet and outlet water close to 10°C@normal mode, 14°C@high performance mode



Liquid pressure	<p>≤350kpa</p> <p>Remarks: when the pressure is more than 300kpa, the water-cooled plate will be deformed and cause the risk of coolant leakage.</p>
Liquid medium	<p>First-level deionized water: meet the requirements of the national standard GB/T 6682-2008 first-level deionized water</p> <p>Notice:                      1) If the water conductivity is ≥100us/cm, the medium must be replaced;                      2) The water conductivity is less than 5us/cm when the system is running for the first time.</p>
Liquid PH	Control range: 6~8
Liquid medium circulation system(Machine side)	<ul style="list-style-type: none"> <li><input type="checkbox"/> Anti-rust and anti-corrosion of pipeline;</li> <li><input type="checkbox"/> The particle diameter of the liquid medium is ≤53 microns, that is, the circulation system is equipped with a 270 mesh filter;</li> <li><input type="checkbox"/> Before connecting the cabinet to the heat dissipation system, clean and filter the system pipeline with deionized water to remove dust, welding slag and other impurities;</li> <li><input type="checkbox"/> The temperature resistance of system components is above 85 °C;</li> <li><input type="checkbox"/> The circulatory system is recommended to be equipped with a UV lamp sterilization device to prevent the liquid from breeding bacteria and attenuate the heat dissipation capacity of the system;</li> <li><input type="checkbox"/> The system is equipped with a 4bar safety relief valve;</li> <li><input type="checkbox"/> The system is equipped with a constant pressure expansion tank.</li> </ul> <p>Note: when the temperature of the coolant rises after the miner is turned on the pressure will rise.</p>
Humidity	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working humidity: 5%RH~85%RH (non-condensing)</li> <li><input type="checkbox"/> Storage humidity: 5%RH~95%RH (non-condensing)</li> <li><input type="checkbox"/> Long-term storage humidity: 30%RH~69%RH (no condensation)</li> </ul>

Remarks: The above liquid temperature and flow parameters are based on deionized water as the liquid medium. If the liquid medium uses antifreeze, the liquid temperature and flow parameters need to be calculated separately. Table 2 shows an example of 30% glycol antifreeze temperature and flow parameters.

Table2 Example of temperature and flow parameters of 30% ethylene glycol antifreeze

Temperature	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working temperature (inlet): 15 °C~45 °C@normal mode 15 °C~35 °C@high performance mode</li> <li><input type="checkbox"/> Inlet temperature control accuracy ± 2 °C</li> <li><input type="checkbox"/> Storage and transportation temperature: -40~70 °C</li> </ul> <p>Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.</p>
Flow	<ul style="list-style-type: none"> <li><input type="checkbox"/> Limited Data: ≥11L/min</li> <li><input type="checkbox"/> Flow control accuracy ± 10%</li> </ul> <p>Remarks: The temperature difference between the inlet and outlet liquids at this flow rate is close to 10 °C@normal mode, 14 °C@high-performance mode)</p>

# WHATSMINER M33S+

## Hydro Cooling



### SPECIFICATION

Hashrate	198T ± 10%
Power Ratio	34J/T ± 5%
PSU	AC380V, 3W+ ground, input 10kw
Size	86mm*482.6mm*650mm
Weight	Net weight: 27.5kg    Weight with packaging materials: 30kg
Coolant demand per machine	About 1L
Power Cable Model	Custom made
Internet Connections	Ethernet

### ENVIRONMENTAL PARAMETERS

Liquid temperature	<input type="checkbox"/> Working temperature (inlet): 20°C~50°C@normal mode 20°C~40°C@high performance mode; <input type="checkbox"/> Inlet temperature control accuracy ± 2°C <input type="checkbox"/> Storage and transportation temperature: -40~70°C
--------------------	---

Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.

Liquid flow	<input type="checkbox"/> Limited Data: ≥10L/min <input type="checkbox"/> Flow control accuracy ± 10%
-------------	---

Remarks: 10L/min corresponds to the temperature difference between inlet and outlet water close to 10°C@normal mode, 14°C@high performance mode

Liquid pressure	<p>≤350kpa</p> <p>Remarks: when the pressure is more than 300kpa, the water-cooled plate will be deformed and cause the risk of coolant leakage.</p>
Liquid medium	<p>First-level deionized water: meet the requirements of the national standard GB/T 6682-2008 first-level deionized water</p> <p>Notice:                      1) If the water conductivity is ≥100us/cm, the medium must be replaced;                      2) The water conductivity is less than 5us/cm when the system is running for the first time.</p>
Liquid PH	Control range: 6~8
Liquid medium circulation system(Machine side)	<ul style="list-style-type: none"> <li><input type="checkbox"/> Anti-rust and anti-corrosion of pipeline;</li> <li><input type="checkbox"/> The particle diameter of the liquid medium is ≤53 microns, that is, the circulation system is equipped with a 270 mesh filter;</li> <li><input type="checkbox"/> Before connecting the cabinet to the heat dissipation system, clean and filter the system pipeline with deionized water to remove dust, welding slag and other impurities;</li> <li><input type="checkbox"/> The temperature resistance of system components is above 85℃;</li> <li><input type="checkbox"/> The circulatory system is recommended to be equipped with a UV lamp sterilization device to prevent the liquid from breeding bacteria and attenuate the heat dissipation capacity of the system;</li> <li><input type="checkbox"/> The system is equipped with a 4bar safety relief valve;</li> <li><input type="checkbox"/> The system is equipped with a constant pressure expansion tank.</li> </ul> <p>Note: when the temperature of the coolant rises after the miner is turned on the pressure will rise.</p>
Humidity	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working humidity: 5%RH~85%RH (non-condensing)</li> <li><input type="checkbox"/> Storage humidity: 5%RH~95%RH (non-condensing)</li> <li><input type="checkbox"/> Long-term storage humidity: 30%RH~69%RH (no condensation)</li> </ul>

Remarks: The above liquid temperature and flow parameters are based on deionized water as the liquid medium. If the liquid medium uses antifreeze, the liquid temperature and flow parameters need to be calculated separately. Table 2 shows an example of 30% glycol antifreeze temperature and flow parameters.

Table2 Example of temperature and flow parameters of 30% ethylene glycol antifreeze

Temperature	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working temperature (inlet): 15℃~45℃@normal mode 15℃~35℃@high performance mode</li> <li><input type="checkbox"/> Inlet temperature control accuracy ± 2℃</li> <li><input type="checkbox"/> Storage and transportation temperature: -40~70℃</li> </ul> <p>Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.</p>
Flow	<ul style="list-style-type: none"> <li><input type="checkbox"/> Limited Data: ≥11L/min</li> <li><input type="checkbox"/> Flow control accuracy ± 10%</li> </ul> <p>Remarks: The temperature difference between the inlet and outlet liquids at this flow rate is close to 10℃@normal mode, 14℃@high-performance mode)</p>

# WHATSMINER M53

## Hydro Cooling



### SPECIFICATION

Hashrate	226T $\pm$ 10%
Power Ratio	29J/T $\pm$ 5%
PSU	AC380V, 3W+ ground, input 10kw
Size	86mm*482.6mm*663mm with handle
Weight	Net weight: 27.5kg    Weight with packaging materials: 30kg
Coolant demand per machine	About 1L
Power Cable Model	Custom made
Internet Connections	Ethernet

### ENVIRONMENTAL PARAMETERS

#### Liquid temperature

- Working temperature (inlet): 20°C~50°C@normal mode  
20°C~40°C@high performance mode;
- Inlet temperature control accuracy  $\pm$  2°C
- Storage and transportation temperature: -40~70°C

Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.

#### Liquid flow

- Limited Data:  $\geq$ 10L/min
- Flow control accuracy  $\pm$  10%

Remarks: 10L/min corresponds to the temperature difference between inlet and outlet water close to 10°C@normal mode, 14°C@high performance mode



Liquid pressure	<p>≤350kpa</p> <p>Remarks: when the pressure is more than 300kpa, the water-cooled plate will be deformed and cause the risk of coolant leakage.</p>
Liquid medium	<p>First-level deionized water: meet the requirements of the national standard GB/T 6682-2008 first-level deionized water</p> <p>Notice:                      1) If the water conductivity is ≥100us/cm, the medium must be replaced;                      2) The water conductivity is less than 5us/cm when the system is running for the first time.</p>
Liquid PH	Control range: 6~8
Liquid medium circulation system(Machine side)	<ul style="list-style-type: none"> <li><input type="checkbox"/> Anti-rust and anti-corrosion of pipeline;</li> <li><input type="checkbox"/> The particle diameter of the liquid medium is ≤53 microns, that is, the circulation system is equipped with a 270 mesh filter;</li> <li><input type="checkbox"/> Before connecting the cabinet to the heat dissipation system, clean and filter the system pipeline with deionized water to remove dust, welding slag and other impurities;</li> <li><input type="checkbox"/> The temperature resistance of system components is above 85 ℃;</li> <li><input type="checkbox"/> The circulatory system is recommended to be equipped with a UV lamp sterilization device to prevent the liquid from breeding bacteria and attenuate the heat dissipation capacity of the system;</li> <li><input type="checkbox"/> The system is equipped with a 4bar safety relief valve;</li> <li><input type="checkbox"/> The system is equipped with a constant pressure expansion tank.</li> </ul> <p>Note: when the temperature of the coolant rises after the miner is turned on the pressure will rise.</p>
Humidity	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working humidity: 5%RH~85%RH (non-condensing)</li> <li><input type="checkbox"/> Storage humidity: 5%RH~95%RH (non-condensing)</li> <li><input type="checkbox"/> Long-term storage humidity: 30%RH~69%RH (no condensation)</li> </ul>

Remarks: The above liquid temperature and flow parameters are based on deionized water as the liquid medium. If the liquid medium uses antifreeze, the liquid temperature and flow parameters need to be calculated separately. Table 2 shows an example of 30% glycol antifreeze temperature and flow parameters.

Table2 Example of temperature and flow parameters of 30% ethylene glycol antifreeze

Temperature	<ul style="list-style-type: none"> <li><input type="checkbox"/> Working temperature (inlet): 15 ℃~45 ℃@normal mode 15 ℃~35 ℃@high performance mode</li> <li><input type="checkbox"/> Inlet temperature control accuracy ± 2 ℃</li> <li><input type="checkbox"/> Storage and transportation temperature: -40~70 ℃</li> </ul> <p>Note: please empty the liquid in the equipment during storage and transportation. If it is not emptied, ensure that the equipment is above the freezing point of the liquid.</p>
Flow	<ul style="list-style-type: none"> <li><input type="checkbox"/> Limited Data: ≥11L/min</li> <li><input type="checkbox"/> Flow control accuracy ± 10%</li> </ul> <p>Remarks: The temperature difference between the inlet and outlet liquids at this flow rate is close to 10 ℃@normal mode, 14 ℃@high-performance mode)</p>

# WHATSMINER M50S

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	126T ± 5%	Size	430mm*155mm*226mm
Power Ratio	26J/T ± 5%@25° C	Weight	11.7KG
Power On Wall	3276W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

# WHATSMINER M50

## Air Cooling



### Components

Power Supply, Fan, Control Board, Hash Board, Case

### Flashing Light Introduction

Blinking Green Light:  
Working normally

Green and Red Lights Alternately Flashing:  
Alarm status and need to find the response error code

### Safety Guidelines

1. Please check if there is any obvious physical failure before power on, beware of electric shock
2. The product must be kept away from water sources and must not be operated in a humid environment
3. It requires professionals to carry out daily maintenance on the product
4. It is forbidden to directly touch the product by hand when power is on
5. Please use the stable voltage

### Warranty Period

One year after leaving the factory

### After-sales Contact Information

1. Email: [Support@microbt-whatminer.com](mailto:Support@microbt-whatminer.com)
2. Telegram Group: @WhatsMiner Community

## SPECIFICATION

Hashrate	112T ± 5%	Size	430mm*155mm*226mm
Power Ratio	29J/T ± 5%@25° C	Weight	11.7KG
Power On Wall	3248W ± 10%	Internet Connections	Ethernet
Working Temperature	-5° C ~ 35° C	Power Cable Model	IEC C19, ≥16A
PSU Model	P221B/P222B AC220V ~ 240V		

## CONTACT US

TEL : +86 755-26640921

Business Cooperation : [Marketing@microbt-whatsminer.com](mailto:Marketing@microbt-whatsminer.com)

Sales Consulting : [Sales@microbt-whatsminer.com](mailto:Sales@microbt-whatsminer.com)

Technical Support : [Support@microbt-whatsminer.com](mailto:Support@microbt-whatsminer.com)

Download : Enter [www.microbt-whatsminer.com](http://www.microbt-whatsminer.com) and  
click on the navigation bar support,  
then click download



Shenzhen MicroBT Electronics Technology Co., Ltd.

 @Whatsminer\_MBT

 @WhatsMiner

 @WhatsMiner Community